



Industrial Automation Headquarters

Delta Electronics, Inc.
Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.
Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province, P.R.C. 215200
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.
238 Min-Xia Road, Pudong District,
ShangHai, P.R.C. 201209
TEL: 86-21-58635678 / FAX: 86-21-58630003

Delta Electronics (Japan), Inc.
Tokyo Office
2-1-14 Minato-ku Shibadaimon,
Tokyo 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.
1511, Byucksan Digital Valley 6-cha, Gasan-dong,
Geumcheon-gu, Seoul, Korea, 153-704
TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd.
4 Kaki Bukit Ave 1, #05-05, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.
Plot No 43 Sector 35, HSIIDC
Gurgaon, PIN 122001, Haryana, India
TEL : 91-124-4874900 / FAX : 91-124-4874945

Americas

Delta Products Corporation (USA)
Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3800 / FAX: 1-919-767-8080

Delta Greentech (Brasil) S.A.
Sao Paulo Office
Rua Itapeva, 26 - 3° andar Edificio Itapeva One-Bela Vista
01332-000-São Paulo-SP-Brazil
TEL: 55 11 3568-3855 / FAX: 55 11 3568-3865

Europe

Deltronics (The Netherlands) B.V.
Eindhoven Office
De Witbogt 20, 5652 AG Eindhoven, The Netherlands
TEL: 31-40-2592850 / FAX: 31-40-2592851



DOP eRemote User Manual

*We reserve the right to change the information in this manual without prior notice.

2014-07-10

www.deltaww.com



Table of Contents

Chapter 1	Introduction	1-1
1.1	eRemote Remote Control Software	1-1
1.2	Supported Models.....	1-2
1.3	System Requirement	1-2
Chapter 2	Software Installation	2-1
2.1	eRemote Setup	2-1
2.1.1	Software Installation	2-1
Chapter 3	Working with eRemote	3-1
3.1	Update Firmware.....	3-1
3.2	Start eRemote	3-2
3.3	Connection	3-3
3.4	Menu Reference	3-6
3.4.1	Connection.....	3-6
3.4.2	Zoom	3-6
3.4.3	Tool	3-7
3.4.4	Help	3-8
Appendix A	Testing Example.....	A-1
A.1	Networking Settings.....	A-1
A.2	Create Testing Example	A-4
Appendix B	Upload / Download via Ethernet.....	B-1
B.1	Environment Settings	B-1
B.2	Communicate Settings	B-3
B.3	Compile and Upload / Download All Data.....	B-8

About this Manual...

User Information

Be sure to store this manual in a safe place.

Due to constantly growing product range, technical improvement and alteration or changed texts, figures and diagrams, we reserve the right of this manual contained information change without prior notice.

Coping or reproducing any part of this manual, without written consent of Delta Electronics Inc. is prohibited.

Technical Support and Service

Welcome to contact us or visit our web site (<http://www.delta.com.tw/industrialautomation/>) if you need any technical support, service and information, or, if you have any question in using the product. We are looking forward to serve you needs and willing to offer our best support and service to you. Reach us by the following ways.

ASIA

DELTA ELECTRONICS, INC.
TAOYUAN Plant/
31-1, SHIEN PAN ROAD, KUEI SAN
INDUSTRIAL ZONE TAOYUAN 333, TAIWAN
TEL: 886-3-362-6301
FAX: 886-3-362-7267

JAPAN

DELTA ELECTRONICS (JAPAN) INC.
Sales Office/
DELTA SHIBADAIMON BLDG.
2-1-14 SHIBADAIMON, MINATO-KU,
TOKYO, 105-0012, JAPAN
TEL: 81-3-5733-1111
FAX: 81-3-5733-1211

NORTH/SOUTH AMERICA

DELTA PRODUCTS CORPORATION
Sales Office/
P.O. BOX 12173
5101 DAVIS DRIVE,
RESEARCH TRIANGLE PARK, NC 27709,
U.S.A.
TEL: 1-919-767-3813
FAX: 1-919-767-3969


EUROPE

DELTRONICS (NETHERLANDS) B.V.
Sales Office/
DE WITBOGT 15, 5652 AG EINDHOVEN,
THE NETHERLANDS
TEL: 31-40-259-2860
FAX: 31-40-259-2851

Chapter 1 Introduction

1.1 eRemote Remote Control Software

eRemote is a PC software used to help the customers view and check the same screen shown on HMI at the production site, and control the manufacturing process via Ethernet. No matter where you are, remote controlling is not an arduous task at all.



1.2 Supported Models

The supported models for eRemote Remote Control Software are listed in the table below.

Series	Model Name	Remark
DOP-AE Series	DOP-AE57BSTD	DOP series Extension Ethernet Module, DOP-EXLNHJ1AE is required when using eRemote with DOP-AE series HMI product.
	DOP-AE57GSTD	
	DOP-AE57CSTD	
	DOP-AE80THTD1	
	DOP-AE10THTD1	
DOP-B Series	DOP-B03E211	
	DOP-B07E415	
	DOP-B07E515	
	DOP-B08E515	
	DOP-B10E615	

1.3 System Requirement

Below are the system requirements to comply with the operating environment of eRemote:

Hardware / Software	System Requirement
CPU	Pentium 4, 2GHz or greater is recommended
Memory	1GB and above is recommended
Hard Disk	Capacity: 50MB and above
Monitor	Support resolution: 1024 × 768 or higher full-color display.
Printer	Printer compatible with Windows® 2000 & Windows® XP
Operation System	Windows 2000/WindowsXP/Windows Vista/Windows7

Chapter 2 Software Installation


2.1 eRemote Setup

In this chapter, it will introduce general functions of eRemote with Windows. The users can use it to design what they want. Detail information for each function will be discussed in the following chapters.

2.1.1 Software Installation

To start the eRemote setup, please refer to the following steps:


Step 1. Please start-up your computer to Windows 2000/WindowsXP system.



Step 2. Execute **setup.exe** from Windows taskbar by clicking **“Start”** > **“Run”**. After pressing **OK**, the system will setup automatically and the following dialog box will appear for selecting the desired display language.



Step 3. After pressing **OK**, the system will setup automatically and the users will get the following dialog box to choose destination location.




To select the default directory

C: \Program Files\Delta Industrial Automation\DOP eRemote 2.xx.xx, click **Next>** for the next step. Setup will install in the directory indicated in the Destination Directory box at the bottom of the dialog box.


To select a directory other than the default directory, click **Browse**. A list of available directories appears. Highlight the desired directory for the Delta eRemote and click **OK**, then **Next>** for the next step.

If necessary, click **< Back** button to take you back through Setup dialog boxes one by one.


Step 4. After pressing **Next**, the following dialog box will appear and ask the users to select the installation software, i.e. DOP eRemote. Then click **Install** button to start DOP eRemote installation.



Step 5. The system will start DOP eRemote Installation.



Step 6. DOP eRemote has been installed successfully. Press **Close** to finish the installation.




Chapter 3 Working with eRemote


Before using eRemote, the users need to update HMI firmware. Please ensure to read the following instructions fully so that the users could understand how to update HMI firmware correctly.

3.1 Update Firmware

Remember to update the firmware before using eRemote. To select this function, click **Start > Programs > Delta Industrial Automation > HMI > DOP eRemote 2.xx.xx > Update Firmware Tool**.



After clicking **Update Firmware Tool**, the following dialog box will appear for the users to select the communication interface (the default setting is USB driver). Press **Update** button to update HMI firmware automatically.




3.2 Start eRemote

To start eRemote, click **Start > Programs > Delta Industrial Automation > HMI > DOP eRemote 2.xx.xx > eRemote**.




3.3 Connection


After starting eRemote, click **Connection > New** from menu bar to create a new connection.




The following **IP Address Setup** dialog box will appear, and the system will search and show all of the connecting HMIs via Ethernet automatically. Select the desired HMI and press **OK** button.



User could type domain name to connect with eRemote.




Before connection, the password is required. Please enter the correct password and press **OK** button.









After entering the correct password, the system will start the connection automatically. After the connection is successfully established, the users can monitor and control HMI screens on the computer screen.

3.4 Menu Reference

eRemote provide three options function menu for Connection, Zoom, Tool and Help.




And, also provide user to select icon to execute 【 New Connection】 , 【 Close Connection】 、 【 Zoom In】 、 【 Zoom Out】 、 【 Full Screen】 與 【 Help】 .





3.4.1 Connection


Function	
Create Remote Control Connection	
New	Create a new connection
Close	Close the current connection
Language	Select the display language. It supports Traditional Chinese, Simplified Chinese and English.
Exit	Exit the eRemote

3.4.2 Zoom

Function	
Determine the view of the eRemote screen	
Zoom in	Increase the magnification of the screen. The largest magnification available is 300%.
Zoom out	Reduce the magnification of the screen. The smallest magnification available is 25%.
Full Screen	Set the Screen to Full Screen as monitor.
	Press right key of mouse to select 【Zoom in】 、 【Zoom out】 or 【Reset】 to cancel the full screen 。 
Zoom reset	Reset the magnification of the screen to 100%.

3.4.3 Tool

Function	
About print screen	
Print Screen	Print screen function could provide user print currently remote screen.
HTTP	<p>This function could use web page to remote HMI.</p> <p>Step1. Into Tool and select HTTP.</p>  <p>Step2. Check Enable HTTP. The Port default value is 80. When open each web page, the port should set different. If start the first web page, the port is 81, then start the second web page, the port should set to be 82.</p>  <p>Step3. After setting, please start browser and type IP address of PC like http://172.16.190.54:81.</p> <p>User could check your PC IP address at command window, type ipconfig to check current IP address.</p>  <p>Step4. Please type http://172.16.190.54:81 on browser, if user could see as below screen it means connect successful.</p> <p>Please type password, the default password is 12345678. After typing correct password, press Login, user could use web page to control HMI.</p>  <p>If type correct IP address of PC, but it still cannot connect, please turn of the proxy of PC and reconnect again.</p>

Function	
	<p>It will appear as below message when HTTP service cannot start. Please check the port if conflict or not.</p> 

3.4.4 Help


Function	
About eRemote	
About	Show the various items of legal information of eRemote.

Appendix A Testing Example


Before creating testing example, make sure to change the upload and download option (**Options > Configuration**) on DOPSoft first. The default setting of upload and download is via **USB**. If the users need to use **Ethernet**, please change the default setting by referring to **Appendix B**.

A.1 Networking Settings


Ensure to observe the following instructions to complete PC networking settings before eRemote operation.




Power on PC and start Windows. Click **Start > Programs**, point to **Control Panel**, and then select **Network Connections**.




Double-click **Network Connections** icon, the following windows will appear. Right-click the **Local Area Connection** icon, and then select **Properties** from the pop-up menu.



The **Local Area Connection Properties** dialog box will open. Use **General** tab to select **Internet Protocol (TCP/IP)**. Then, press **Properties** button.



The **Internet Protocol (TCP/IP) Properties** dialog box will open. Choose **Use the following IP address** and enter the IP address numbers of the PC into the field of **IP address** and **Subnet mask**.




Then, press **OK** button to finish the settings.


Please note that if the IP address numbers of subnet masks of the PC and HMI are different, HMI may not be displayed in the list when finding node.

A.2 Create Testing Example

Start DOPSoft Software program and click **File > New** or click **New** icon to create a new project. Then, click **Element > Button > Maintained** to create a Maintained element (\$0.0) and click **Element > Input > Numeric Entry** to create a numeric entry element (\$10) on the screen. In this case, 10 inches color B10E615 type DOP series HMI is used.




Click **Options > Communication Setting** and choose **Ethernet** tab then select LocalHost and complete HMI networking settings and **Enable** Network shown as the figure below. Then, press **OK** button to finish the settings.




After **OK** button is pressed, HMI networking is completed. Compile the edited project file at the end of the programming and the edited project file could be transferred to HMI.

Then, start the eRemote and click **Connection > New** from menu bar to create a new connection. The following **IP Address Setup** dialog box will appear, and the system will search and show all of the connecting HMIs via Ethernet automatically. Select the **HMI** and IP Address is **172.16.190.51** then press **OK** button.



After selected HMI, eRemote will asking user to input password to create connection. The default password is 12345678.



At this time, the users are able to monitor and control HMI screens on the computer screen.




Appendix B Upload / Download via Ethernet

B.1 Environment Settings

The default setting of upload and download on DOPSoft is via **USB**. If the users need to use **Ethernet**, please activate DOPSoft and select **Options > Environment** to access the configuration options and change the upload and download setting.




In **Environment** dialog box, change the default setting of upload and download to **Ethernet**. Then, press **OK** to complete the setting.




B.2 Communication Setting

If the users choose to use DHCP mode, please into **Options > Communication Setting > Ethernet > LocalHost** to enable **Obtain an IP address automatically**.




If the users choose to use user-defined IP address, please into **Options > Communication Settings > Ethernet > LocalHost** and set HMI IP Address then ensure that the domain name is the same as the IP address of the personal computer.




After Ethernet IP address is set, the users can enter into the system menu to verify if the IP address is written correctly or not.




Then, observe the following instructions to complete PC networking settings.




Power on PC and start Windows. Click **Start > Programs**, point to **Control Panel**, and then select **Network Connections**.




Double-click **Network Connections** icon, the following windows will appear. Right-click the **Local Area Connection** icon, and then select **Properties** from the pop-up menu.



The **Local Area Connection Properties** dialog box will open. Use **General** tab to select **Internet Protocol (TCP/IP)**. Then, press **Properties** button.



The Internet Protocol (TCP/IP) Properties dialog box will open. Choose **Use the following IP address** and enter the IP address numbers of the PC into the field of IP address and Subnet mask.





Then, press **OK** button to finish the settings.


Please note that if the IP address numbers of subnet masks of the PC and HMI are different, HMI may not be displayed in the list when finding node.

B.3 Compile and Upload / Download All Data


After completing PC networking settings, compile the editing program immediately. When compile operation is performed successfully, choose **Upload all Data** or **Download all Data** next.



Then, the following dialog box will appear.



The users can check the box before **Auto Search**, and the system will detect the connecting HMI automatically.



When the connecting HMI is found, press Start button, and the system will start to upload or download the screen data via Ethernet immediately.