

BECKHOFF TCP/IP PLC

HMI Factory Setting:

Controller IP Address: 192.168.0.1

Controller COM Port: 48898

Controller Station Number: 1

Control Area / Status Area: DW0/DW10

Connection

Standard Jumper Cable / Network Cable without jumper (Auto-detected by HMI)

Definition of PLC Read/Write Address

a. Registers

Type	Format	Read/Write Range	Data Length	Note
	Word No. (n)			
Input Relay	IWn	IW0 – IW65534	Word	1
Output Relay	QWn	QW0 – QW65534	Word	1
Internal Relay	MWn	MW0 – MW65534	Word	1
Data Area	DWn	DW0 - DW2097150	Word	1

b. Contacts

Type	Format	Read/Write Range	Note
	Bit No. (b)		
Input Relay	IXn	IX0.0 – IX65535.7	
Output Relay	QXn	QX0.0 – QX65535.7	
Internal Relay	MXn	MX0.0 – MX65535.7	
Data Area	DXn	DX0 - DX16777215	

NOTE

- 1) Device address must be an even number.

- 2) Please set Sender AMS NetId、Target AMS NetId、ADS Port in Communication Setting → Extra Parameter.

