
EXTENSION PORT
60
16.3
3
90
33
DVPSCM12
POWER
RUN
ERR
TX1
RX1
RS485
RS422
TERM1
ON
OFF
COM1
TX+
TX-
RX+
RX-
SG
SG
D+
D-
SG
TERM2
ON
OFF
TX2
RX2
RS485
RS422
COM2
TX+
TX-
RX+
RX-
SG
SG
D+
D-
SG